



## Formulary

### Illuminating Face Powder - Using Bichromas

Phase	Trade Name	INCI Name	Supplier	Formula # <b>205-39</b>
A	Talc MM3D1	Talc, Dimethicone, Magnesium Myristate	<b>Sandream</b>	29.00
A	Zinc Stearate	Zinc Stearate	Brenntag	6.25
A	Bi-Glo 0120	Bismuth Oxychloride	<b>Sandream</b>	6.00
A	Micropoly 250S	Polyethylene	Micro Powders Inc.	5.25
A	PMMA-H	Polymethylmethacrylate	Brenntag	1.00
A	Aerosil R972	Fumed Silica	Aerosil	0.60
A	Bichroma Red	Bismuth Oxychloride, Mica, Iron Oxides, Magnesium Stearate	<b>Sandream</b>	2.10
A	Bichroma Yellow	Bismuth Oxychloride, Mica, Iron Oxides, Magnesium Stearate	<b>Sandream</b>	2.20
A	Bichroma Black	Bismuth Oxychloride, Mica, Iron Oxides, Magnesium Stearate	<b>Sandream</b>	0.25
B	Mica LL3	Mica, Lauryl Lysine	<b>Sandream</b>	28.35
B	SD Soft White Sn110	Mica, TiO2, SiO2, SnO2	<b>Sandream</b>	4.50
B	SD Soft Gold SL100	Mica, TiO2, SiO2, SnO2	<b>Sandream</b>	4.50
C	Octyldodecyl Oliviate	Octyldodecyl Oleate	<b>Sandream</b>	3.00
C	Schercemol OHS	Ethylhexyl hydroxystearate	Lubrizol	5.00
C	Phenoxyethanol	Phenoxyethanol	Jeen	1.00
C	Vitamin E	Tocopheryl Acetate	<b>Sandream</b>	0.50
C	Methyl Paraben	Methyl 4-hydroxybenzoate	<b>Sandream</b>	0.30
C	Beeswax SP-422P	Beeswax	Stahl and Pitsch	0.10
C	Propyl Paraben	Propyl 4-hydroxybenzoate	<b>Sandream</b>	0.10
<b>TOTAL PERCENT</b>				100

**Procedure:** Premix Phase A in osterizer blender and mix thoroughly until well blended. Add phase B to A and gently mix for 1 minute. Preweigh phase C into glass beaker and heat to 70°C and stir until all is dissolved and uniform. Add phase C to A and B and blend for one minute. Scrape down sides and repeat blending process. Fill into desired pans and press!